

Features

Please note that it is very important to the health of your stylus that you put the stylus guard in place before installation.



The base unit has an adhesive strip on the bottom which holds the lifter in place. The base unit is separate from the lifter and allows it to move horizontally for fine tuning the trigger position and also vertically for different tone arm heights.



Lift force sensitivity is a slider that allows you to adjust how much force will be needed to lift your specific tonearm off the record. The higher the slider the gentler the lift.



The trigger sensitivity adjustor moves the trigger allowing you to select the correct position for firing the lifter. Please note that when this adjustor is all the way up The Q UP will not work. ALL THE WAY UP IS THE OFF POSITION.



The trigger is the part of The Q up which ultimately comes into contact with the tonearm when the record has reached the end of play.



The tonearm lifter elevates the tonearm when the trigger is fired.